

Anziehvorschrift Zylinderkopf

Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

752.763

passend für / suitable for
adaptable à / adaptable a


Toyota



Das Original


Schraubenkopf / Head shape
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



708.240

M 12x1,25x107/126



Anziehen/
Tightening/
Serrage/
Apriete

40 Nm
80 Nm
118 Nm

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

93,5 mm Ø

Corona MK2	Mot.2L	1983>1988
Cressida LX70	Mot.2L	1983>1988
Crown LS120	Mot.2L	1983>1988
Hiace LH51, 61, 71	Mot.2L	1983>1988
Hilux LN51, 56, 60	Mot.2L	1983>1988
Toyocae LY31L	Mot.2L	1983>1988

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

26/06/25

752.763